


MAXON[®]

M-04-08
APRIL 2004

MAINTENANCE
MANUAL

80 SERIES



MAXON[®]

LIFT CORP.

11921 Slauson Ave.
Santa Fe Springs, CA. 90670

CUSTOMER SERVICE:

TELEPHONE (562) 464-0099 TOLL FREE (800) 227-4116

FAX: (888) 771-7713

NOTE: For latest version of all Manuals (and replacements), download the Manuals from Maxon's website at www.maxonlift.com.

WARRANTY/ RMA POLICY & PROCEDURE

LIFTGATE WARRANTY

Type of Warranty: Full Parts and Labor

Term of Warranty: Standard Liftgates - 2 years from ship date or 6,000 cycles
Premium Liftgates - 2 years from ship date or 10,000 cycles

This warranty shall not apply unless the product is installed, operated and maintained in accordance with MAXON Lift's specifications as set forth in MAXON Lift's Installation, Operation and Maintenance manuals. This warranty does not cover normal wear, maintenance or adjustments, damage or malfunction caused by improper handling, installation, abuse, misuse, negligence, or carelessness of operation. In addition, this warranty does not cover equipment that has had unauthorized modifications or alterations made to the product.

MAXON agrees to replace any components which are found to be defective during the first 2 years of service, and will reimburse for labor based on MAXON's Liftgate Warranty Flat Rate Schedule. (Copy of the Flat Rate is available at www.maxonlift.com.)

All warranty repairs must be performed by an authorized MAXON warranty facility. For any repairs that may exceed \$500, including parts and labor, MAXON's Technical Service Department must be notified and an "Authorization Number" obtained.

All claims for warranty must be received within 30 Days of the repair date, and include the following information:

1. Liftgate Model Number and Serial Number
2. The End User must be referenced on the claim
3. Detailed Description of Problem
4. Corrective Action Taken, and Date of Repair
5. Parts used for Repair, Including MAXON Part Number(s)
6. MAXON R.M.A. # and/or Authorization # if applicable (see below)
7. Person contacted at MAXON if applicable
8. Claim must show detailed information i.e. Labor rate and hours of work performed

Warranty claims can also be placed on-line at www.maxonlift.com. On-line claims will be given priority processing.

All claims for warranty will be denied if paperwork has not been received or claim submitted via Maxon website for processing by MAXON's Warranty Department within 30 days of repair date.

All components may be subject to return for inspection, prior to the claim being processed. MAXON products may not be returned without prior written approval from MAXON's Technical Service Department. Returns must be accompanied by a copy of the original invoice or reference with original invoice number and are subject to a credit deduction to cover handling charges and any necessary reconditioning costs. **Unauthorized returns will be refused and will become the responsibility of the returnee.**

Any goods being returned to MAXON Lift must be pre-approved for return, and have the R.M.A. number written on the outside of the package in plain view, and returned freight prepaid. All returns are subject to a 15% handling charge if not accompanied by a detailed packing list. Returned parts are subject to no credit and returned back to the customer.

Defective Parts requested for return must be returned within 30 days of the claim date for consideration to:

MAXON Lift Corp.
16205 Distribution Way, Cerritos, CA 90703
Attn: RMA#___

MAXON's warranty policy does not include the reimbursement for travel time, towing, vehicle rental, service calls, oil, batteries or loss of income due to downtime. Fabrication or use of non Maxon parts, which are available from MAXON, are also not covered.

MAXON's Flat Rate Labor Schedule takes into consideration the time required for diagnosis of a problem.

All Liftgates returned are subject to inspection and a 15% restocking fee. Any returned Liftgates or components that have been installed or not returned in new condition will be subject to an additional reworking charge which will be based upon the labor and material cost required to return the Liftgate or component to new condition.

PURCHASE PART WARRANTY

Term of Warranty: 1 Year from Date of Purchase.

Type of Warranty: Part replacement only

MAXON will guarantee all returned genuine MAXON replacement parts upon receipt and inspection of parts and original invoice.

All warranty replacements parts will be sent out via ground freight. If a Rush Shipment is requested all freight charges will be billed to the requesting party.

TABLE OF CONTENTS

WARNINGS	6
LIFTGATE TERMINOLOGY	7
SERVICE TIME CHART	8
PERIODIC MAINTENANCE	10
PERIODIC MAINTENANCE CHECKLIST	10
CHECKING HYDRAULIC FLUID	11
CHANGING HYDRAULIC FLUID	12
PLATFORM ADJUSTMENT	14
SADDLE ADJUSTMENT	16
REPLACING PLATFORM TORSION SPRING	17
PARTS BREAKDOWN	18
80 SERIES FINAL ASSEMBLY	19
80 SERIES MAIN FRAME & LIFTING FRAME	20
PLATFORM & FLIPOVER ASSY	22
GRAVITY DOWN HYDRAULIC COMPONENTS	24
PUMP BOX ASSEMBLY (GRAVITY DOWN)	25
POWER DOWN HYDRAULIC COMPONENTS	26
PUMP BOX ASSEMBLY (POWER DOWN)	27
CONTROL SWITCH AND POWER CABLE	28
DECALS	29
HYDRAULIC SYSTEM DIAGRAMS	32
HYDRAULIC SCHEMATIC - GRAVITY DOWN	32
HYDRAULIC SCHEMATIC - POWER DOWN	33

TABLE OF CONTENTS - Continued

ELECTRICAL SYSTEM DIAGRAMS	34
ELECTRICAL SCHEMATIC - GRAVITY DOWN	34
ELECTRICAL SCHEMATIC - POWER DOWN.....	35
TROUBLESHOOTING	36
PLATFORM WILL NOT RAISE	36
PLATFORM RAISES BUT LEAKS DOWN.....	37
PLATFORM RAISES PARTIALLY AND STOPS	38
LIFTGATE WILL NOT LIFT RATED CAPACITY	39
PLATFORM RAISES SLOWLY	40
PLATFORM WILL NOT LOWER, LOWERS TOO SLOWLY, OR LOWERS TOO QUICKLY ..	41

Comply with the following **WARNINGS** while maintaining Liftgates. See Operation Manual M-00-37 for operating safety requirements.

▲ WARNINGS

- Read and understand the instructions in this **Maintenance Manual** before performing maintenance on the Liftgate.
- Before operating the Liftgate, read and understand the operating instructions in **Operation Manual M-97-37**.
- Comply with all **WARNING** and instruction decals attached to the Liftgate.
- Keep decals clean and legible. If decals are defaced or missing, replace them. Free replacement decals are available from **Maxon Parts Department**.
- Consider the safety and location of bystanders and location of nearby objects when operating the Liftgate. Stand to one side of the platform while operating the Liftgate
- Do not allow untrained persons to operate the Liftgate.
- Do not stand under, or allow obstructions under the platform when lowering the Liftgate. **Be sure your feet are clear of the Liftgate.**
- **Keep fingers, hands, arms, legs, and feet clear of moving Liftgate parts (and platform edges) when operating the Liftgate.**
- **Correctly stow platform when not in use. Extended platforms could create a hazard for people and vehicles passing by.**
- **Disconnect Liftgate power cable from battery** before repairing or servicing Liftgate.
- Wear appropriate safety equipment such as protective eyeglasses, faceshield and clothing while performing maintenance on the Liftgate and handling the battery. Debris from drilling and contact with battery acid may injure unprotected eyes and skin.
- Be careful working by an automotive type battery. Make sure the work area is well ventilated and there are no flames or sparks near the battery. Never lay objects on the battery that can short the terminals together. If battery acid gets in your eyes, immediately seek first aid. If acid gets on your skin, immediately wash it off with soap and water.
- If an emergency situation arises (vehicle or Liftgate) while operating the Liftgate, release the control Toggle Switch and the Liftgate will stop.
- A correctly installed Liftgate operates smoothly and reasonably quiet. The only noticeable noise during operation comes from the pump unit while the platform is raised. Listen for scraping, grating and binding noises and correct the problem before continuing to operate Liftgate.
- If it is necessary to stand on the platform while maintaining the Liftgate, keep your feet and any objects clear of the inboard edge of the platform. Your feet or objects on the platform could be trapped between the platform and the Liftgate extension plate.
- Never perform unauthorized modifications on the Liftgate. Modifications may result in early failure of the Liftgate and may create hazards for Liftgate operators and maintainers.
- Use only **Maxon Authorized Parts** for replacement parts. Provide Liftgate model and serial number information with your parts order. Order replacement parts from:

MAXON LIFT CORP. Customer Service

11921 Slauson Ave., Santa Fe Springs, CA 90670


Phone: (800) 227-4116

- To order parts by e-mail, submit orders to **partssales@maxonlift.com**.

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

LIFTGATE TERMINOLOGY (80 SERIES)



SERVICE TIME CHART

STRUCTURAL SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE PLATFORM PINS (EACH)	.50
CHANGE ALL PINS	3.00
CHANGE GREASELESS BUSHINGS (EACH)	.25
CHANGE PLATFORM TORSION SPRING	1.00
CHANGE EXTENSION PLATE	1.50
CHANGE LIFTFRAME ASSEMBLY	1.00
CHANGE PARALLEL ARM (EACH)	.50
CHANGE SHACKLES (EACH)	.50
CHANGE PLATFORM OPENER	.50
CHANGE PLATFORM LOCKING LATCH	.50
CHANGE ENTIRE PLATFORM	2.00
CHANGE PLATFORM MAIN SECTION	1.50
CHANGE PLATFORM FOLDING SECTION	1.00
REPLACE FOLDING SECTION HINGE PIN	.50
ADJUST PLATFORM SLOPE	.50

ELECTRICAL SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE MOTOR	1.00
CHANGE MOTOR SOLENOID	.50
CHANGE SOLENOID VALVE COIL (EACH)	.50
CHANGE POWER PACK, COMPLETE	1.00
CHANGE OUTSIDE SWITCH ASSEMBLY	.50
CHANGE CIRCUIT BREAKER	.50
CHANGE TOGGLE SWITCH (EACH)	.50
CHANGE WIRING HARNESS OUTSIDE	1.00

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

HYDRAULIC SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE PUMP ASSEMBLY	1.00
CHANGE PUMP RESERVOIR	1.00
CHANGE AUXILIARY HAND PUMP	1.00
RESET PUMP AND RELIEF VALVE PRESSURE	.50
ADJUST LOWERING SPEED	.25
CHANGE EXTERNAL FLOW CONTROL VALVE	.50
CHANGE/CLEAN CARTRIDGE VALVE	1.00
CHANGE LIFT CYLINDER (EACH)	1.00
CHANGE EXTERNAL HYDRAULIC HOSES (EACH)	.25
CHANGE RETURN LINE (EACH)	.50

PERIODIC MAINTENANCE

PERIODIC MAINTENANCE CHECKLIST



WARNING

Never operate the Liftgate with parts loose or missing.

Annually

Visually check the entire Liftgate for excessively worn parts and broken welds, especially the Hinge Pins. See **PARTS BREAKDOWN** section for replacement parts. Also, do the **Semi-annual** and **Quarterly Maintenance** checks.

Semi-annually

Visually check the Platform Hinge Pins for excessive wear and broken welds. See **PARTS BREAKDOWN** section for replacement parts. Also, do the **Quarterly Maintenance** checks.

Quarterly

Check the Hydraulic Fluid level in the Pump Reservoir. Refer to the **CHECKING HYDRAULIC FLUID** procedure in the **PERIODIC MAINTENANCE** section.

If Hydraulic Fluid appears contaminated, refer to the **CHANGING HYDRAULIC FLUID** procedure in the **PERIODIC MAINTENANCE** section.

Keep track of the grade of Hydraulic Fluid in the Pump Reservoir and never mix two different grades of fluid.

Check all Hoses and Fittings for chaffing and fluid leaks. Replace if necessary.

Check electrical wiring for chaffing and make sure wiring connections are tight and free of corrosion.

Check that all **WARNING** and **instruction decals** are in place and legible.

Check that all roll pins are in place and protrude evenly from both sides of Hinge Pin collar. Replace roll pins if necessary.

Check for rust and oily surfaces on Liftgate. If there is rust or oil on Liftgate, clean it off. Touch up the paint where bare metal is showing.

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

CHECKING HYDRAULIC FLUID

NOTE: Use correct grade of hydraulic fluid for your location.


+70 to +140 Degrees F - Grade ISO 32

+40 to +105 Degrees F - Grade ISO 15

Below + 70 Degrees F - Grade ISO 10 or MIL-H-5606

See TABLES 11-1, 11-2, & 11-3 for recommended brands.

1. Remove the Filler Cap (FIG. 11-1).



**CHECKING HYDRAULIC
FLUID LEVEL
FIG. 11-1**

2. Check the Hydraulic Fluid level in the Pump Reservoir (FIG. 11-1). If fluid is below **FILL LEVEL** shown on Pump Reservoir (FIG. 11-1), add fluid to the **FILL LEVEL**.

3. Reinstall the Filler Cap (FIG. 11-1).

ISO 32 HYDRAULIC OIL	
RECOMMENDED BRANDS	PART NUMBER
AMSOIL	AWH-05
CHEVRON	HIPERSYN 32
KENDALL	GOLDEN MV
SHELL	TELLUS T-32
EXXON	UNIVIS N-32
MOBIL	DTE-13M, DTE-24, HYDRAULIC OIL-13

TABLE 11-1

ISO 15 HYDRAULIC OIL	
RECOMMENDED BRANDS	PART NUMBER
AMSOIL	AWF-05
CHEVRON	FLUID A, AW-MV-15
KENDALL	GLACIAL BLU
SHELL	TELLUS T-15
EXXON	UNIVIS HVI-13
MOBIL	DTE-11M

TABLE 11-2

ISO-10 OR MIL-H-5606 HYDRAULIC FLUID	
RECOMMENDED BRANDS	PART NUMBER
AMSOIL	N/A
CHEVRON	FLUID A, FLUID G
KENDALL	GLACIAL BLU
SHELL	AEROSHELL FLUID-41
EXXON	UNIVIS HVI-13
MOBIL	AERO HFA

TABLE 11-3

PERIODIC MAINTENANCE

CHANGING HYDRAULIC FLUID

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination.


NOTE: Use correct grade of hydraulic fluid for your location.

- | | |
|-----------------------|------------------------------|
| +70 to +140 Degrees F | - Grade ISO 32 |
| +40 to +105 Degrees F | - Grade ISO 15 |
| Below + 70 Degrees F | - Grade ISO 10 or MIL-H-5606 |

See TABLES 9-2, 9-3 & 9-4 on the next page for recommended brands.

GRAVITY DOWN LIFTGATES


1. Place empty 5 Gallon Bucket under Drain Plug.
2. Open and lower Platform to ground. Remove the Drain Plug (**FIG. 12-1**). Drain hydraulic fluid from system. Reinstall Drain Plug.
3. Remove Filler Cap (**FIG. 12-2**). Refill reservoir with hydraulic fluid to the top of **FILL LEVEL** bar shown on decal (**FIG. 12-2**). Reinstall Filler Cap (**FIG. 12-2**).



GRAVITY DOWN PUMP BOX
FIG. 12-1

POWER DOWN LIFTGATES

1. Place empty 5 Gallon Bucket under Drain Plug.
2. Open and raise Platform to vehicle bed height. Remove the Drain Plug (**FIG. 12-1**). Drain hydraulic fluid.
3. Disconnect the Motor Power Cable (**FIG. 12-2**) from Starter Solenoid next to pump. Lower the Platform while draining the remaining hydraulic fluid from system. Reinstall Drain Plug. Reconnect the Motor Power Cable to Starter Solenoid.
4. Remove Filler Cap (**FIG. 12-2**). Refill reservoir with hydraulic fluid to the top of **FILL LEVEL** bar shown on decal (**FIG. 12-2**). Reinstall Filler Cap (**FIG. 12-2**).



POWER DOWN PUMP & MOTOR
FIG. 12-2

THIS PAGE INTENTIONALLY LEFT BLANK

PERIODIC MAINTENANCE




PLATFORM ADJUSTMENT

NOTE: Before doing the following procedure, make sure vehicle is parked on level ground.

1. Make sure Platform is at ground level. Unfold the Platform and Flipover. As the Platform first touches the ground, Shackles and tip of Flipover must touch the ground at the same time (**FIG. 14-1**). If the Shackles and the tip of Flipover touch the ground at the same time, **RAISE** Platform to bed level. Tip of Flipover should be above bed level (**FIG. 14-2**). If indications are correct in both cases (**FIGS. 14-1 & 14-2**), Liftgate is installed correctly and no adjustment is needed. If indications are incorrect, continue with instruction 2.


NOTE: If tip of Flipover touches first (**FIG. 14-3**), do instruction 2. If the Shackle touches first (**FIG. 11-1**), skip instruction 2 and do 3.

2. Make sure Platform is still at ground level. If the Shackle is not touching the ground, measure and compare distance "A" (**FIG. 14-3**) with **TABLE 14-1** to determine the correct shim. Make shims as needed (**FIG. 14-5**). Weld shim as shown in **FIG. 14-4**.




RAISE TIP OF FLIPOVER THIS DISTANCE "A"	REQUIRED SHIM THICKNESS	WELD SIZE "W"
1"	1/16"	1/16"
2"	1/8"	1/8"
3"	3/16"	3/16"
4"	1/4"	1/4"

TABLE 14-1




**SHIM (1/16", 1/8", or 1/4") MADE FROM STEEL FLAT
FIG. 14-5**



**WELDING SHIMS (CURBSIDE SHOWN)
FIG. 14-4**

3. Make sure Platform is still at ground level. If the tip of Flipover is not touching the ground, measure and compare distance "B" (FIG. 15-1) with TABLE 15-1 to determine how much to grind from the Platform Stops (FIG. 15-2). Grind correct amount of metal (TABLE 15-1) from Platform Stop as shown in FIG. 15-2.




PLATFORM DOES NOT TOUCH GROUND
FIG. 15-1

LOWER TIP OF FLIPOVER THIS DISTANCE "B"	GRIND METAL FROM PLATFORM STOP
1"	1/16"
2"	1/8"
3"	3/16"
4"	1/4"

TABLE 15-1


4. RAISE the Platform, then LOWER it to the ground. As the Platform first touches the ground, the tip of Flipover and Shackle should touch at the same time as shown in FIG. 14-1.




GRINDING PLATFORM STOPS
(CURBSIDE SHOWN)
FIG. 15-2

SADDLE ADJUSTMENT

1. Lower Platform to ground level.
2. Remove bolts, lock nuts, and Saddle (**FIG. 16-1B**) from Right Hand (RH) side Mounting Plate. Repeat step for Left Hand (LH) side.



3. Stow the Platform as shown in **FIG. 16-2A**. Use floor jack positioned at center of Platform (near hinge) to raise Platform 1/8" above Roller (**FIG. 16-2B**). Reinstall Saddle, bolts and locknuts on RH side Mounting Plate (**FIG. 16-2A**). Repeat for Saddle on LH side. Butt each Saddle against Platform, and tighten lock nuts.



**GAP BETWEEN PLATFORM & ROLLER
FIG. 16-2B**

MAXON®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

REPLACING PLATFORM TORSION SPRING


NOTE: The following procedure shows how to replace Torsion Spring on RH side of Platform. Use this procedure for replacing Torsion Spring on the LH Side.

1. Fold Flipover onto Platform.
2. Fold Platform.
3. Raise Liftgate to a convenient work height to gain access and release tension on the Torsion Spring.

⚠ CAUTION


To prevent injury and equipment damage, make sure there is no tension on torsion spring before removing hinge pin.

4. Unbolt Hinge Pin from Hinge Bracket (**FIG. 17-1**). Remove bolt and lock nut. Drive the Hinge Pin inboard toward the Shackle just enough to free the torsion spring (**FIG. 17-1**). Remove the Torsion Spring.



**REMOVING HINGE PIN
(RH SIDE OF PLATFORM SHOWN)
FIG. 17-1**

5. Install the Torsion Spring as shown in **FIG. 17-2**. Make sure the long leg of the spring is inserted in the bracket located on Shackle (**FIG. 17-2**). Make sure the short end of the spring is visible and resting against the edge of the Hinge Bracket (**FIG. 17-2**).



**INSTALLING HINGE PIN
(RH SIDE OF PLATFORM SHOWN)
FIG. 17-2**


6. Drive the Hinge Pin into correct position through the Hinge Bracket as shown in **FIG. 17-2**. Line up the bolt hole in the Hinge Pin with the hole in the Hinge Bracket. Bolt the Hinge Pin to Hinge Bracket with bolt and lock nut (**FIG. 17-2**).
7. Operate the Liftgate according to instructions in **Operation Manual M-97-37** to make sure it operates correctly.

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

PARTS BREAKDOWN

80 SERIES FINAL ASSEMBLY




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	226938	EYE,DROP FORGED PAD 3/4" X 1-1/2"
2	1	227700	HOOK ASSEMBLY
3	4	900014-4	BOLT, HEX HEAD 3/8"-16 X 1"
4	2	901011-5	NUT, HEX HEAD 3/8"-16
5	1	226355	EXTENSION PLATE
6	2	902001-2	WASHER, FLAT 3/8"
7	4	902011-4	WASHER, LOCK 3/8"
8	2	266763-01	OPENER ASSEMBLY

80 SERIES MAIN FRAME & LIFTING FRAME

MAXON®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713




80 SERIES MAIN FRAME & LIFTING FRAME

ITEM	QUANTITY	PART NO.	DESCRIPTION
1	4	030034	BOLT, 3/8"-24 X 1" LG. GR8
2	4	030035	BOLT 3/8"-24 X 1-1/4" LG. GR8
3	2	030038	BOLT, 3/8"-24X1-1/2" LG. GR8
4	1	050175	PLATE, MAXON HORIZONTAL
5	4	905112-06	BEARING, SELF LUBE, 1-3/8" X 3/8" LG.
6	6	207644	POP RIVET, 3/16" X 25/64" LG.
7	4	221416	ROLL PIN, 3/8" X 2" LG.
8	2	226358	PIN WELDMENT
9	1	226363-01	TORSION SPRING, 1/2" X 5-3/4" LG. RH
10	1	226363-02	SPRING, TORSION, 1/2" X 5-3/4" LG. LH
11	2	226365	PIN WELDMENT, SHACKLE
12	2	907026	ROLL PIN, 3/16 X 2-1/4" LG.
13	2	226372	ROUND TUBE, 1/4" (2" X 5/16"W)
14	4	226375	ROLLER, 1"
15	8	226941	NYLON LOCK NUT, 3/8"-24 THIN
16	2	261785-01	PARALLEL ARM WELDMENT (WITH BEARINGS)
16A	8	905112-07	BEARING, SELF-LUBE, 1-3/8" X 1-3/4" LG.
17	1	261800-01	LIFT FRAME WELDMENT
17A	4	915112-01	BEARING, SELF-LUBE, 1-3/8" X 3/4" LG.
17B	4	915112-02	BEARING, SELF-LUBE, 1-3/8" X 1" LG.
18	2	262435	PIN WELDMENT, CYLINDER 1-3/8" DIA
19	2	262437	BUSHING WELDMENT-CYL HOSE CLAMP
20	2	262462	PIN WELDMENT, CYL. 1-3/8" DIA
21	2	265807-01	PIN WELDMENT, PLATFORM 1-3/8" X 13-1/8" LG.
22	1	266762-01	SHACKLE ASSY, LH (WITH BEARINGS)
23	1	266762-02	SHACKLE ASSY, RH (WITH BEARINGS)
24	2	266675-01	SADDLE, STEEL PLATFORM
25	1	265866-01	MAIN FRAME WELDMENT
26	14	205780	PLASTIC TIE, 7" LG
27	2	266033-01	PIN WELDMENT, UNDERRIDE
28	4	901023	FLANGE LOCK NUT
29	4	901024-5	BOLT, HEX HEAD, 1/2"-13 X 2-1/4" LG.
30	2	902001-2	FLAT WASHER, 3/8"
31	2	902013-21	FLAT WASHER, 1-3/8"
32	2	905128-07	ROLL PIN 1/8" X 2-1/4" LG
33	2	040103-5	LOOM, SPLIT 1/2" X 5" LG
34	2	266676-01	ROLLER, STEEL 1"

MAXON[®] 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

PLATFORM & FLIPOVER ASSY (WEDGE)




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266652-01	PLATFORM WELDMENT, STEEL
2	1	266665-01	FLIPOVER WELDMENT, STEEL
3	2	251533	PIN, 2-3/8" LG.
4	2	221416	ROLL PIN
5	1	280749-03	ANCHOR BOLT WELDMENT, 1/2"-13
6	1	280751-01	TORSION BAR
7	1	902000-14	FLAT WASHER, 1/2"
8	1	901010	NYLON LOCK NUT, 1/2"-13

MAXON®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

THIS PAGE INTENTIONALLY LEFT BLANK

GRAVITY DOWN HYDRAULIC COMPONENTS




ITEM	QTY.	PART NO.	DESCRIPTION
1	2	266038-01	CYLINDER, 3" BORE (80-3)
	2	266039-01	CYLINDER, 3.5" BORE (80-4)
1A	1	266038SK-01	SEAL KIT (3" BORE CYLINDER)
	1	266039SK-01	SEAL KIT (3.5" BORE CYLINDER)
2	1	265846-01	HOSE ASSY 3/8"HP SAE#8F,#6M 21" LG.
3	1	22437-17	PLASTIC HOSE, 14" X 30" LG
4	1	265888-01	HOSE ASSY, 3/8"HP, SAE#8 F-F 57" LG.
5	1	224370-13	PLASTIC HOSE, 14" X 75" LG.
6	1	224370-12	PLASTIC HOSE, 14" X 55" LG.
7	1	265888-02	HOSE ASSY, 3/8"HP, SAE#6 F-F, 77" LG.
8	1	215406	ELBOW, BRASS, 1/4" X 3/8"
9	1	905150	TEE, UNION 3/8" F.S. MALE,6-JLO
10	2	906704-01	ELBOW, STRAIGHT THREAD #8 F/S O-R M-M
11	2	906705-01	CONNECTOR, LONG, NPSC, SAE #6
12	1	906711-01	TEE, UNION AIRBRAKE, 1/4"
13	2	906707-01	ELBOW, STRAIGHT THREAD F/S O-R #6 M-M
14	1	906708-01	ELBOW, STRAIGHT THREAD F/S O-R #6 M-F SW
15	1	906709-01	VALVE, FLOW REGULATOR #6 SAE, 4GPM
16	8	906712-02	O-RING, #6 (3/8" FACE SEAL TUBE-END)
17	2	228012	AADAPTER, STRAIGHT THD. 9/16" TO 1/4" PIPE

MAXON


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

PUMP BOX ASSEMBLY (GRAVITY DOWN)



ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266016-01	PUMP BOX WELDMENT
2	1	229383	PUMP BOX COVER
2A	2	215139	CATCH & FASTENER
3	1	205780	PLASTIC TIE
4	1	280566-01	GREEN WIRE ASSEMBLY, 16GA
5	1	266014-01	PUMP ASSEMBLY, GRAVITY DOWN
5A	1	280374	MOTOR, 12 VOLTS DC
5B	1	280372	SOLENOID VALVE, 12 VOLTS DC
5C	1	906721-01	RESERVOIR
5D	1	280394	MOTOR STARTER SOLENOID, 12 VOLTS DC
5E	1	280416	WIRE ASSEMBLY (16GA)
5F	1	280404	CABLE ASSEMBLY (2GA)
5G	1	229193	FILLER, BREATHER
5H	1	266030-01	DRAIN PLUG
6	1	REF	DECAL (SEE DECAL SECTION)

POWER DOWN HYDRAULIC COMPONENTS




ITEM	QTY.	PART NO.	DESCRIPTION
1	2	266038-01	CYLINDER, 3" BORE (80-3)
	2	266039-01	CYLINDER, 3.5" BORE (80-4)
1A	1	266038SK-01	SEAL KIT (3" BORE CYLINDER)
	1	266039SK-01	SEAL KIT (3.5" BORE CYLINDER)
2	1	265846-01	HOSE ASSY, 3/8"HP SAE#8F,#6M, 21" LG.
3	1	265847-01	HOSE ASSY, 3/8"HP SAE#6 F-F, 28" LG.
4	1	265888-01	HOSE ASSY, 3/8"HP SAE#8 F-F, 57" LG.
5	1	265888-02	HOSE ASSY, 3/8"HP SAE#8 F-F, 83" LG.
6	1	265889-01	HOSE ASSY, 3/8"HP SAE#6 F-F, 55" LG.
7	1	265889-02	HOSE ASSY, 3/8"HP SAE#6 F-F, 77" LG.
8	1	906709-01	VALVE,FLOW REGULATOR #6 SAE, 4GPM
9	1	905150	TEE, UNION, 3/8" F/S MALE,6-JLO
10	2	906704-01	ELBOW, STRAIGHT THR. #8F/S O-RING M-M
11	2	906705-01	CONNECTOR, LONG STR, THD SAE #6
12	1	906706-01	TEE, UNION SAE#8 F/S M-M
13	2	906707-01	ELBOW, STRAIGHT THD. #6F/S O-RING M-M
14	1	906708-01	ELBOW, STRAIGHT THD F/S O-RING #6M-F SW
15	6	906712-02	O-RING #6 (3/8" FACE SEAL TUBE-END)
16	5	906712-03	O-RING #8 (1/2" FACE SEAL TUBE-END)

MAXON®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713


PUMP BOX ASSEMBLY (POWER DOWN)




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266016-01	PUMP BOX WELDMENT
2	1	229383	PUMP BOX COVER
2A	2	215139	CATCH & FASTENER
3	1	REF	DECAL (SEE DECAL SECTION)
4	1	205780	PLASTIC TIE
5	1	266030-01	PUMP ASSEMBLY, POWER DOWN
5A	1	280381	MOTOR, 12 VOLTS DC
5B	2	280394	MOTOR STARTER SOLENOID, 12 VOLTS DC
5C	2	906719-01	VALVE
5D	2	906720-01	10 VDC COIL
5E	1	906721-01	RESERVOIR
5F	2	280402	CABLE ASSEMBLY (2 GA)
5G	1	280543	CABLE ASSEMBLY (2 GA)
5H	1	229193	FILLER-BREATHER
5I	1	REF	DRAIN PLUG, 3/8"-18 NPTF

CONTROL SWITCH AND POWER CABLE

NOTE: Use Switch to **RAISE** and **LOWER** Liftgate to make sure Switch operates as shown on the decal.





ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266032-01	CABLE ASSEMBLY, 16GA / 3 WIRE
2	1	264346	SWITCH & CABLE
3	2	900057-5	SCREW, SELF-TAPPING #10-24 X 1" LG.
4	1	905206	SWITCH BOOT SEAL
5	1	264422	CABLE ASSEMBLY, 200 AMPS, 38' LG.



⚠ WARNING
 Do not attach cable to battery until liftgate repairs are completed.

DECALS



CAUTION DECAL
P/N 263998

⚠ WARNING

READ THIS INFORMATION CAREFULLY

- Improper operation of this Lift can result in serious personal injury. Do not operate unless you have been properly instructed and have read, and are familiar with the operating instructions. If you do not have a copy of the instructions, please obtain them from your employer, distributor, or lessor, before you attempt to operate Lift.
- Be certain that the vehicle is properly and securely braked before using the Lift.
- Always inspect this Lift for maintenance or damage before using it. If there are signs of improper maintenance, damage to vital parts, or slippery Platform surface, do not use the Lift until these problems have been corrected.
- Do not overload the Lift. The load limit is based on evenly distributed cargo over the entire Platform surface. If you are using a pallet jack, be sure it can be maneuvered safely. Do not operate a forklift on the Platform or travel with the platform in an open position at any time.
- Load should be placed in a stable position close to the edge of the Platform nearest the truck. The heaviest portion of the load should never be placed beyond the center of the Platform away from the truck.
- Never allow yourself, a helper, or bystander to stand in a position where a falling load could land on either of you. Also do not allow any part of yours or your helper's body to be placed under, within, or around any portion of the moving liftgate, or its mechanisms, or in a position that would trap them between the platform and the ground or truck when the liftgate is operated.
- If a helper is riding the Platform with you, make sure you are both doing so safely and that you are not in danger of coming in contact with any moving or potentially moving obstacles. USE GOOD COMMON SENSE. If load appears to be unsafe, do not lift or lower it.

For a free copy of other manuals that pertain to this model Liftgate, please visit our website at www.maxonlift.com or call **Customer Service at (800) 227-4116**.

MAXON LIFT CORP.PART NO. 264081


WARNING DECAL
P/N 264081

MAXON® 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

DECALS - CONTINUED

MAXON®


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



**UP/DOWN DECAL
P/N 264507**

**WARNING DECAL
P/N 264081
(REFERENCE)**

**CAUTION DECAL
P/N 263998
(REFERENCE)**



THE MAXIMUM CAPACITY
OF THIS LIFT IS

POUNDS

WHEN THE LOAD IS
CENTERED ON PLATFORM

CAPACITY DECAL (SEE TABLE 30-1)

LIFT CAPACITY DECALS	
CAPACITY	PART NO.
2500 LBS.	220382
3000 LBS.	220388
4000 LBS.	220389
5000 LBS.	220390

TABLE 30-1

OPERATING INSTRUCTIONS


GPT & 80 SERIES LIFTGATES

- 1** UNHOOK SAFETY CHAIN.
(SEE CAUTION DECAL.)
- 2** PUSH CONTROL SWITCH

(MUST TOUCH THE GROUND)
- 3** UNFOLD PLATFORM.
- 4** UNFOLD FLIPOVER.
- 5** USE SWITCH TO RAISE / LOWER.
- 6** TO TUCK UNIT AWAY REVERSE STEPS 1, 2, 3, & 4.

DECAL, P/N 251838

**INSTRUCTION DECAL
P/N 251838**




HYDRAULIC FLUID LEVEL


**FILL
LEVEL**





1. Platform must be open and on the ground to check hydraulic fluid level (see illustration). Remove Filler Cap and look in filler hole. Reservoir is full if fluid level is even with top of **FILL LEVEL** bar.
2. If fluid level is lower than top of **FILL LEVEL** bar, add hydraulic fluid (see **SPECS**). Fill until fluid level is even with top of **FILL LEVEL** bar. Re-install Filler Cap.



HYDRAULIC FLUID GRADES


 +140°F Use
 + 70° F ISO - 32


 + 105° F Use
 + 40° F ISO - 15


 + 70° F & Below
 Use ISO - 10 or
 MIL - H - 5606

P/N 265330-03


FLUID LEVEL DECAL
P/N 265330-03

HYDRAULIC SYSTEM DIAGRAMS


HYDRAULIC SCHEMATIC - GRAVITY DOWN

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



HYDRAULIC SCHEMATIC - POWER DOWN




ELECTRICAL SYSTEM DIAGRAMS


ELECTRICAL SCHEMATIC - GRAVITY DOWN

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



ELECTRICAL SCHEMATIC - POWER DOWN



MAXON[®] 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

TROUBLESHOOTING

PLATFORM WILL NOT RAISE

1. Connect voltmeter between Motor Solenoid Terminal "A" and Bracket (**FIG. 36-1**) to verify that battery power is getting to "A". Recharge the battery if voltmeter indicates less than 12.6 Volts DC.

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

2. Fill Reservoir to within 1/2" below the top with the hydraulic fluid recommended in the Periodic Maintenance Checklist.
3. Touch a jumper wire to terminals "A" & "C" (**FIG. 36-1**). If motor runs check Switch, switch connections, and White wire. Check and correct wiring connections or replace the Switch.
4. Touch heavy jumper cables to terminals "A" & "B" (**FIG. 36-1**).
 - a. If motor runs, replace the motor solenoid.
 - b. If motor does not run, repair or replace the pump motor.

NOTE: In most cases, you can avoid having to manually bleed Hydraulic System by correctly positioning Liftgate Platform before disconnecting any Lifting Cylinder high pressure Hydraulic Lines. The following procedure can save time and prevent accidental fluid spills and hazards.

5. Check for structural damage and replace worn parts.
6. Check filter in the pump Reservoir. Replace filter if necessary.
7. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.




FIG. 36-1

PLATFORM RAISES BUT LEAKS DOWN

1. Check if Lowering Solenoid Valve is constantly energized. Connect voltmeter negative (-) lead to Motor Solenoid bracket and positive (+) lead to Motor Solenoid terminal "C" (FIG. 37-1). If voltmeter reads battery voltage (+12.6 Volts DC minimum) without pushing the toggle switch, the control circuit is operating incorrectly. Check if toggle switch, wiring or coil are faulty.




FIG. 37-1

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

NOTE: In most cases, you can avoid having to manually bleed Hydraulic System by correctly positioning Liftgate Platform before disconnecting any Lifting Cylinder high pressure Hydraulic Lines. The following procedure can save time and prevent accidental fluid spills and hazards.

2. Check the Valve Stem by removing the Coil Assembly (FIG. 37-2, Item 1). With platform supported, unscrew the Valve Stem (FIG. 37-2, Item 2) from the Pump. Push on the plunger located inside the Valve Stem with a small screwdriver. If the Plunger does not move freely (approximately 1/8") replace the Valve Stem.
3. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (FIG. 37-3). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.




FIG. 37-2




FIG. 37-3

TROUBLESHOOTING

PLATFORM RAISES PARTIALLY AND STOPS

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

1. Lower the opened Platform to the ground. Fill the Pump Reservoir on Gravity-Down Liftgates to within 1/2" below the top with hydraulic fluid recommended in Periodic Maintenance Checklist.
2. Use voltmeter to verify that the Battery shows 12.6 volts or more.
3. Check for Structural damage, or poor lubrication. Replace worn parts.

NOTE: In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

4. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 39-1**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.
5. Check Filter in the Pump Reservoir. Replace filter if necessary.
6. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.

MAXON[®]

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

LIFTGATE WILL NOT LIFT RATED CAPACITY

1. Use voltmeter to verify that the Battery shows 12.6 volts or more under load from pump motor.
2. Check for Structural damage or lack of lubrication. Replace worn parts.

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

NOTE: In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

3. With Platform on the ground, remove the pressure hose and fitting from the Pump and replace it with a 0-3000 PSI Pressure Gauge. Hold the switch in the "UP" position. Adjust the Relief Valve on the side of the Pump until the gauge shows 2800 to 3000 PSI (**FIG. 39-2**). Remove gauge and re-install pressure hose.
4. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.
5. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 39-1**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.
6. If Pump cannot produce 2800-3000 PSI with a minimum of 12.6 Volts available, the Pump is worn and needs to be replaced.




FIG. 39-1





FIG. 39-2

RELIEF VALVE
ADJUST SCREW

TROUBLESHOOTING PLATFORM RAISES SLOWLY

1. Connect voltmeter between Motor Solenoid Terminal "A" and Bracket (**FIG. 40-1**) to verify that battery power is getting to "A". Recharge the battery if voltmeter indicates less than 12.6 Volts DC.



TERMINAL "A"
(VOLTMETER
+ LEAD)

FIG. 40-1

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

2. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 40-3**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.

NOTE: In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

3. Check and clean Flow Control Valve (**FIG. 40-2**) in high pressure hydraulic line attached to Cylinder. When installing Flow Control Valve make sure arrow on valve is oriented as shown in **FIG. 40-2**.




FIG. 40-2

4. Lower the opened Platform to the ground. Fill the Pump Reservoir on Gravity Down Liftgates to within 1/2" below the top with hydraulic fluid recommended in Periodic Maintenance Checklist.
5. Verify the Pump Motor is grounded to the vehicle frame.
6. Check for leaking hoses and fittings. Tighten or replace as required.
7. Check for structural damage or poor lubrication. Replace worn parts.
8. Check the Filter in the Pump Reservoir. Replace if necessary.




FIG. 40-3

9. With Platform on the ground, remove the pressure hose and fitting from the Pump and replace it with a 0-3000 PSI Pressure Gauge. Hold the Control switch in the "RAISE" position. Adjust the Relief Valve on the side of the Pump until the gauge shows 2800 to 3000 PSI (**FIG. 40-3**). Remove gauge and reinstall pressure hose.

PLATFORM WILL NOT LOWER, LOWERS TOO SLOWLY, OR LOWERS TOO QUICKLY

1. Connect voltmeter between Motor Solenoid Terminal "A" and Bracket (**FIG. 41-1**) to verify that battery power is getting to "A". Recharge the battery if voltmeter indicates less than 12.6 Volts DC.
2. Check for structural damage or poor lubrication. Replace worn parts.
3. Check if Lowering Solenoid Valve is getting power. Connect voltmeter between Motor Solenoid Bracket and Motor Solenoid terminal "C" (**FIG. 41-1**). Push Control Switch to "LOWER" position to energize Lowering Solenoid. If voltmeter reads battery voltage (+12.6 Volts DC minimum), control circuit is operating correctly (replace Lowering Solenoid). If voltmeter reads 0 Volts, check if toggle switch and wiring are faulty.




FIG. 41-1

CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

NOTE: In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

4. Check the Valve Stem by removing the Coil Assembly (**FIG. 41-2, Item 1**). With platform supported, unscrew the Valve Stem (**FIG. 41-2, Item 2**) from the Pump. Push on the plunger located inside the Valve Stem with a small screwdriver. If the Plunger does not move freely (approximately 1/8") replace the Valve Stem.
5. Check if filtering screen on solenoid valve is plugged. Clean carefully if required.
6. Check and clean Flow Control Valve in high pressure hydraulic line attached to Cylinder.
7. Check if Flow Control Valve (**FIG. 41-3**) is pointing to the direction of restricted fluid flow (back toward pump). If required, remove Flow Control Valve and install it correctly (**FIG. 41-3**).




FIG. 41-2




FIG. 41-3

