


**MAXON<sup>®</sup>**

M-97-28  
REV. D  
JANUARY 2003

**MAINTENANCE**   
**MANUAL**

**80 SERIES**





# MAXON<sup>®</sup>

## LIFT CORP.

11921 Slauson Ave.  
Santa Fe Springs, CA. 90670

### CUSTOMER SERVICE:

TELEPHONE (562) 464-0099 TOLL FREE (800) 227-4116

FAX: (888) 771-7713

NOTE: For latest version Manuals (and replacements), download  
Manuals from Maxon's website at [www.maxonlift.com](http://www.maxonlift.com).

## WARRANTY/ RMA POLICY & PROCEDURE

### LIFTGATE WARRANTY

Term of Warranty: 2 Years from Date of In-Service (In service date cannot exceed 3 months from ship date.)

Type of Warranty: Full Parts and Labor

This warranty shall not apply unless the product is installed, operated and maintained in accordance with MAXON Lift's specifications as set forth in MAXON Lift's Installation, Operation and Maintenance manuals. This warranty does not cover normal wear, maintenance or adjustments, damage or malfunction caused by improper handling, installation, abuse, misuse, negligence, or carelessness of operation. In addition, this warranty does not cover equipment that has had unauthorized modifications or alterations made to the product.

MAXON agrees to replace any components which are found to be defective during the first 2 years of service, and will reimburse for labor based on MAXON's Liftgate Warranty Flat Rate Schedule. (Copy of the Flat Rate is available at [www.maxonlift.com](http://www.maxonlift.com).)

All warranty repairs must be performed by an authorized MAXON warranty facility. For any repairs that may exceed \$500, including parts and labor, MAXON's Technical Service Department must be notified and an "Authorization Number" obtained.

All claims for warranty must be received within 30 Days of the repair date, and include the following information:

1. Liftgate Model Number and Serial Number
2. The End User must be referenced on the claim
3. Detailed Description of Problem
4. Corrective Action Taken, and Date of Repair
5. Parts used for Repair, Including MAXON Part Number(s)
6. MAXON R.M.A. # and/or Authorization # if applicable (see below)
7. Person contacted at MAXON if applicable
8. Claim must show detailed information i.e. Labor rate and hours of work performed

Warranty claims can also be placed on-line at [www.maxonlift.com](http://www.maxonlift.com). On-line claims will be given priority processing.

All claims for warranty will be denied if paperwork has not been received or claim submitted via Maxon website for processing by MAXON's Warranty Department within 30 days of repair date.

All components may be subject to return for inspection, prior to the claim being processed. MAXON products may not be returned without prior written approval from MAXON's Technical Service Department. Returns must be accompanied by a copy of the original invoice or reference with original invoice number and are subject to a credit deduction to cover handling charges and any necessary reconditioning costs. **Unauthorized returns will be refused and will become the responsibility of the returnee.**

Any goods being returned to MAXON Lift must be pre-approved for return, and have the R.M.A. number written on the outside of the package in plain view, and returned freight prepaid. All returns are subject to a 15% handling charge if not accompanied by a detailed packing list. Returned parts are subject to no credit and returned back to the customer.

Defective Parts requested for return must be returned within 30 days of the claim date for consideration to:

**MAXON Lift Corp.**  
**16205 Distribution Way, Cerritos, CA 90703**

Attn: RMA#\_\_

MAXON's warranty policy does not include the reimbursement for travel time, towing, vehicle rental, service calls, oil, batteries or loss of income due to downtime. Fabrication or use of non Maxon parts, which are available from MAXON, are also not covered.

MAXON's Flat Rate Labor Schedule takes into consideration the time required for diagnosis of a problem.

All Liftgates returned are subject to inspection and a 15% restocking fee. Any returned Liftgates or components that have been installed or not returned in new condition will be subject to an additional reworking charge which will be based upon the labor and material cost required to return the Liftgate or component to new condition.

### PURCHASE PART WARRANTY

Term of Warranty: 1 Year from Date of Purchase.

Type of Warranty: Part replacement only

MAXON will guarantee all returned genuine MAXON replacement parts upon receipt and inspection of parts and original invoice.

All warranty replacements parts will be sent out via ground freight. If a Rush Shipment is requested all freight charges will be billed to the requesting party.

# TABLE OF CONTENTS

<b>WARNINGS</b> .....	<b>6</b>
LIFTGATE TERMINOLOGY .....	7
SERVICE TIME CHART .....	8
PERIODIC MAINTENANCE CHECKLIST .....	10
CHANGING HYDRAULIC FLUID .....	11
<b>ADJUSTMENTS</b> .....	<b>13</b>
PLATFORM ADJUSTMENT .....	14
SADDLE ADJUSTMENT .....	16
REPLACING PLATFORM TORSION SPRING .....	17
<b>PARTS BREAKDOWN</b> .....	<b>18</b>
80 SERIES FINAL ASSEMBLY .....	19
80 SERIES MAIN FRAME & LIFTING FRAME .....	20
PLATFORM & FLIPOVER ASSY (NO CART STOP) .....	22
PLATFORM & FLIPOVER ASSY (SINGLE CART STOP) .....	23
FLIPOVER (SINGLE CART STOP) .....	24
PLATFORM & FLIPOVER ASSY (DUAL CART STOP) .....	25
FLIPOVER (DUAL CART STOP) .....	26
HYDRAULIC COMPONENTS - GRAVITY DOWN .....	28
PUMP BOX ASSEMBLY - GRAVITY DOWN .....	29
HYDRAULIC COMPONENTS - POWER DOWN .....	30
PUMP BOX ASSEMBLY - POWER DOWN .....	31
CONTROL SWITCH AND POWER CABLE .....	32
DECALS .....	33

## TABLE OF CONTENTS - Continued

<b>SCHEMATICS .....</b>	<b>36</b>
HYDRAULIC SCHEMATIC - GRAVITY DOWN .....	37
ELECTRICAL SCHEMATIC - GRAVITY DOWN .....	38
HYDRAULIC SCHEMATIC - POWER DOWN .....	39
ELECTRICAL SCHEMATIC - POWER DOWN .....	40
<b>TROUBLESHOOTING .....</b>	<b>41</b>
PLATFORM WILL NOT RAISE .....	42
PLATFORM RAISES BUT LEAKS DOWN .....	43
PLATFORM RAISES PARTIALLY AND STOPS .....	44
LIFTGATE WILL NOT LIFT RATED CAPACITY .....	45
PLATFORM RAISES SLOWLY .....	46
PLATFORM WILL NOT LOWER, LOWERS TOO SLOWLY, OR LOWERS TOO QUICKLY ..	47

Comply with the following **WARNINGS** while maintaining Liftgates. See Operation Manual M-00-37 for operating safety requirements.

## **WARNINGS**

- Read and understand the instructions in this **Maintenance Manual** before performing maintenance on the Liftgate.
- Before operating the Liftgate, read and understand the operating instructions in Operation Manual M-97-37.
- Comply with all **WARNING** and instruction decals attached to the Liftgate.
- Keep decals clean and legible. If decals are defaced or missing, replace them. Free replacement decals are available from **Maxon Parts Department**.
- Consider the safety and location of bystanders and location of nearby objects when operating the Liftgate. Stand to one side of the platform while operating the Liftgate
- Do not allow untrained persons to operate the Liftgate.
- Do not stand under, or allow obstructions under the platform when lowering the Liftgate. **Be sure your feet are clear of the Liftgate.**
- **Keep fingers, hands, arms, legs, and feet clear of moving Liftgate parts (and platform edges) when operating the Liftgate.**
- **Correctly stow platform when not in use. Extended platforms could create a hazard for people and vehicles passing by.**
- **Disconnect Liftgate power cable from battery** before repairing or servicing Liftgate.
- Wear appropriate safety equipment such as protective eyeglasses, faceshield and clothing while performing maintenance on the Liftgate and handling the battery. Debris from drilling and contact with battery acid may injure unprotected eyes and skin.
- Be careful working by an automotive type battery. Make sure the work area is well ventilated and there are no flames or sparks near the battery. Never lay objects on the battery that can short the terminals together. If battery acid gets in your eyes, immediately seek first aid. If acid gets on your skin, immediately wash it off with soap and water.
- If an emergency situation arises (vehicle or Liftgate) while operating the Liftgate, release the control Toggle Switch and the Liftgate will stop.
- A correctly installed Liftgate operates smoothly and reasonably quiet. The only noticeable noise during operation comes from the pump unit while the platform is raised. Listen for scraping, grating and binding noises and correct the problem before continuing to operate Liftgate.
- If it is necessary to stand on the platform while maintaining the Liftgate, keep your feet and any objects clear of the inboard edge of the platform. Your feet or objects on the platform could be trapped between the platform and the Liftgate extension plate.
- Never perform unauthorized modifications on the Liftgate. Modifications may result in early failure of the Liftgate and may create hazards for Liftgate operators and maintainers.
- Use only **Maxon Authorized Parts** for replacement parts. Provide Liftgate model and serial number information with your parts order. Order replacement parts from:


**MAXON LIFT CORP. Customer Service**  
**11921 Slauson Ave., Santa Fe Springs, CA 90670**  
**Phone: (800) 227-4116**

- To order parts by e-mail, submit orders to [partssales@maxonlift.com](mailto:partssales@maxonlift.com).

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# LIFTGATE TERMINOLOGY (80 SERIES)



# SERVICE TIME CHART

STRUCTURAL SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE PLATFORM PINS (EACH)	.50
CHANGE ALL PINS	3.00
CHANGE GREASELESS BUSHINGS (EACH)	.25
CHANGE PLATFORM TORSION SPRING	1.00
CHANGE EXTENSION PLATE	1.50
CHANGE LIFTFRAME ASSEMBLY	1.00
CHANGE PARALLEL ARM (EACH)	.50
CHANGE SHACKLES (EACH)	.50
CHANGE PLATFORM OPENER	.50
CHANGE PLATFORM LOCKING LATCH	.50
CHANGE ENTIRE PLATFORM	2.00
CHANGE PLATFORM MAIN SECTION	1.50
CHANGE PLATFORM FOLDING SECTION (ALUMINUM)	1.00
REPLACE FOLDING SECTION HINGE PIN (ALUMINUM)	2.00
ADJUST PLATFORM SLOPE	.50

ELECTRICAL SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE MOTOR	1.00
CHANGE MOTOR SOLENOID	.50
CHANGE SOLENOID VALVE COIL (EACH)	.50
CHANGE POWER PACK, COMPLETE	1.00
CHANGE OUTSIDE SWITCH ASSEMBLY	.50
CHANGE CIRCUIT BREAKER	.50
CHANGE TOGGLE SWITCH (EACH)	.50
CHANGE WIRING HARNESS OUTSIDE	1.00

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



HYDRAULIC SERVICE TO BE PERFORMED	TIME REQ'D. (HOURS)
CHANGE PUMP ASSEMBLY	1.00
CHANGE PUMP RESERVOIR	1.00
CHANGE AUXILIARY HAND PUMP	1.00
RESET PUMP AND RELIEF VALVE PRESSURE	.50
ADJUST LOWERING SPEED	.25
CHANGE EXTERNAL FLOW CONTROL VALVE	.50
CHANGE/CLEAN CARTRIDGE VALVE	1.00
CHANGE LIFT CYLINDER (EACH)	1.00
CHANGE EXTERNAL HYDRAULIC HOSES (EACH)	.25
CHANGE RETURN LINE (EACH)	.50

# PERIODIC MAINTENANCE CHECKLIST



## WARNING

Never operate the Liftgate with parts loose or missing.

### Annually

Visually check the entire Liftgate for excessively worn parts and broken welds, especially the Hinge Pins. See **PARTS BREAKDOWN** section for replacement parts. Also, do the **Semi-annual** and **Quarterly Maintenance** checks.

### Semi-annually

Visually check the Platform Hinge Pins for excessive wear and broken welds. See **PARTS BREAKDOWN** section for replacement parts. Also, do the **Quarterly Maintenance** checks.

### Quarterly

Check the Hydraulic Fluid level in the Pump Reservoir. If hydraulic fluid must be added, select the correct grade of fluid to use at your location.

**+20 to +150 Degrees F - Grade ISO 32**  
**Below + 20 Degrees F - Grade ISO 15**

If Hydraulic Fluid appears contaminated, refer to the **CHANGING HYDRAULIC FLUID** procedure on following page.

Keep track of the grade of Hydraulic Fluid in the Pump Reservoir and never mix two different grades of fluid.

Check all Hoses and Fittings for chaffing and fluid leaks. Replace if necessary.

Check electrical wiring for chaffing and make sure wiring connections are tight and free of corrosion.

Check that all **WARNING and instruction decals** are in place and legible.

Check that all roll pins are in place and protrude evenly from both sides of Hinge Pin collar. Replace roll pins if necessary.

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# CHANGING HYDRAULIC FLUID

## CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination.


**NOTE:** To prevent spills, drain used hydraulic fluid through a funnel into waste fluid container.

### GRAVITY DOWN LIFTGATES

1. Place empty 5 Gallon Bucket under Drain Plug.
2. Open and lower Platform to ground. Remove the Drain Plug (**FIG. 1A**). Drain hydraulic fluid from system. Re-install Drain Plug.
3. Remove Filler Cap (**FIG. 1B**), Refill reservoir with hydraulic fluid to the top of **FILL LEVEL** bar shown on decal (**FIG.1B**). Use correct grade of hydraulic fluid for your location.

**+20 to +150 Degrees F - Grade ISO 32**  
**Below + 20 Degrees F - Grade ISO 15**

4. Re-install Filler Cap (**FIG. 1A**).




**GRAVITY DOWN PUMP BOX**  
**FIG. 1A**

### POWER DOWN LIFTGATES

1. Place empty 5 Gallon Bucket under Drain Plug.
2. Open and raise Platform to vehicle bed height. Remove the Drain Plug (**FIG. 1A**). Drain hydraulic fluid.
3. Disconnect the White Wire (**FIG. 1B**) from Motor Solenoid. Lower the Platform while draining the remaining hydraulic fluid from system. Re-install Drain Plug. Reconnect the White Wire to Motor Solenoid.
4. Remove Filler Cap (**FIG. 1B**). Refill reservoir with hydraulic fluid to the top of **FILL LEVEL** bar shown on decal (**FIG.1B**). Use correct grade of hydraulic fluid for your location.

**+20 to +150 Degrees F - Grade ISO 32**  
**Below + 20 Degrees F - Grade ISO 15**

5. Raise Platform to vehicle bed height. Check hydraulic fluid again. If needed, add more hydraulic fluid until level is at the top of the **FILL LEVEL** bar shown on decal (**FIG. 1B**).
6. Re-install Filler Cap (**FIG. 1B**).



**POWER DOWN PUMP & MOTOR**  
**FIG. 1B**

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

**THIS PAGE INTENTIONALLY LEFT BLANK**

# ADJUSTMENTS

# PLATFORM ADJUSTMENT

**NOTE:** Before doing the following procedure, make sure vehicle is parked on level ground.


1. Make sure Platform is at ground level. Unfold the Platform and Flipover. The Shackles and the outboard edge of Platform must touch the ground at the same time as shown in **FIG. 5**. If the Shackles and the outboard edge of Platform are touching the ground, **RAISE** Platform to bed height. Outboard edge of Platform should be above bed level (**FIG. 4**). If indications are correct (**FIGS. 4 & 5**), Liftgate is installed correctly and no adjustment is needed. If indications are incorrect, continue with instruction 2.

2. If the platform is level at bed level (**FIG. 6**), if Shackles do not touch the ground (**FIG. 7**), or if edge of Platform does not touch the ground (**FIG. 8**), inspect each of the Hinge Pins for visible wear before adjusting the Platform. Replace Hinge Pins that are visibly worn. Refer to Parts Breakdown section of this manual for repair parts.


3. Check Liftgate for structural damage that may cause incorrect platform positioning. Repair structural damage.

**NOTE:** If the Platform is like **FIG. 7** and there is no structural damage or damaged hinge pins, do instruction 4. If the Shackle touches and the Platform edge does not (**FIG. 8**), skip 4 and do 5.


4. Make sure Platform is still at ground level. If the Shackle is not touching the ground, measure and compare distance "A" (**FIG. 7**) with **TABLE 1** to determine the correct shim. Make shims as needed (**FIG. 9**). Weld shim as shown in **FIG. 10**.




**PLATFORM EDGE ABOVE BED LEVEL**  
**FIG. 4**




**PLATFORM & SHACKLES TOUCH GROUND**  
**FIG. 5**



**PLATFORM EDGE AT BED LEVEL**  
**FIG. 6**




**SHACKLES DO NOT TOUCH GROUND**  
**FIG. 7**



**PLATFORM DOES NOT TOUCH GROUND**  
**FIG. 8**


5. Make sure Platform is still at ground level. If edge of the Platform is not touching the round, measure and compare distance "B" (FIG. 8) with TABLE 2 to determine how much to grind from the Platform Stops (FIG. 11). Grind correct amount of metal (TABLE 2) from Platform Stop as shown in FIG. 11.



SHIM (1/16", 1/8", or 1/4") MADE FROM STEEL FLAT  
FIG. 9

RAISE PLATFORM EDGE (OUTBOARD) THIS DISTANCE ("A")	REQUIRED SHIM THICKNESS	WELD SIZE "W"
1"	1/16"	1/16"
2"	1/8"	1/8"
3"	3/16"	3/16"
4"	1/4"	1/4"


TABLE 1



WELDING SHIMS (CURBSIDE SHOWN)  
FIG. 10

LOWER PLATFORM EDGE (OUTBOARD) THIS DISTANCE ("B")	GRIND METAL FROM PLATFORM STOP
1"	1/16"
2"	1/8"
3"	3/16"
4"	1/4"

TABLE 2




GRINDING PLATFORM STOPS (CURBSIDE SHOWN)  
FIG. 11


6. RAISE the Platform, then LOWER it to the ground. Platform and Shackle should touch the ground at the same time as shown in FIG. 5.

# SADDLE ADJUSTMENT

1. Lower Platform to ground level.
2. Remove bolts, lock nuts, and Saddle (**FIG. 2B**) from Right Hand side (RH) Mounting Plate. Repeat step for Left Hand (LH) side.



3. Stow the Platform as shown in **FIG. 3A**. Use floor jack positioned at center of Platform (near hinge) to raise Platform 1/8" above Roller (**FIG. 3B**). Reinstall Saddle, Bolts and Locknuts on RH side Mounting Plate (**FIG. 3A**). Repeat for Saddle on LH side. Butt each Saddle against Platform, and tighten lock nuts.



**GAP BETWEEN PLATFORM & ROLLER  
FIG. 3B**

**MAXON**®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



# REPLACING PLATFORM TORSION SPRING

1. Manually fold Flipover onto Platform.
2. Raise Platform to a convenient work height to gain access and release tension on the Torsion Spring.

**CAUTION**  
To prevent injury and equipment damage, make sure there is no tension on torsion spring before removing hinge pin.

3. Unbolt Hinge Pin from Hinge Bracket (**FIG. 4**). Remove bolt and lock nut. Drive the Hinge Pin inboard toward the Shackle with a hammer and pin punch, just enough to free the torsion spring (**FIG. 4**). Remove spring from Shackle.




FIG. 4

4. Install the Torsion Spring as shown in **FIG. 5**. Make sure the long leg of the spring is inserted in the bracket located on Shackle (**FIG. 5**). Make sure the short end of the spring is visible and resting against the edge of the Hinge Bracket (**FIG. 5**).

5. Drive the Hinge Pin into correct position through the Hinge Bracket with a hammer and pin punch as shown in **FIG. 5**. Line up the bolt hole in the Hinge Pin with the hole in the Hinge Bracket. Bolt the Hinge Pin to Hinge Bracket with bolt and lock nut (**FIG. 5**).




FIG. 5


6. Operate the Liftgate to make sure it operates correctly.

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# PARTS BREAKDOWN

# 80 SERIES FINAL ASSEMBLY




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	226938	EYE, DROP FORGED PAD 3/4" X 1-1/2"
2	1	227700	HOOK ASSEMBLY
3	4	900014-4	BOLT, HEX HEAD 3/8-16 X 1"
4	2	901011-5	NUT, HEX HEAD 3/8-16 UNC-2B
5	1	226355	EXTENSION PLATE
6	2	902001-2	WASHER, FLAT 3/8" X 1/16"
7	4	902011-4	WASHER, LOCK 3/8" X 15/16"
8	1	265994-01	OPENER ASSEMBLY
8A	1	030805	COTTER PIN 1/8" X 1"
8B	1	280082-01	ROLLER
8C	1	905202-03	PIN

# 80 SERIES MAIN FRAME & LIFTING FRAME

**MAXON**®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713




# 80 SERIES MAIN FRAME & LIFTING FRAME

ITEM	QUANTITY	PART NO.	DESCRIPTION
1	4	030034	BOLT, 3/8"-24 X 1" LG. GR8
2	4	030035	BOLT 3/8"-24 X 1-1/4" LG. GR8
3	2	030038	BOLT, 3/8"-24X1-1/2" LG. GR8
4	1	050175	PLATE, MAXON HORIZONTAL
5	4	905112-06	BEARING, SELF LUBE, 1-3/8" X 3/8" LG.
6	6	207644	POP RIVET, 3/16" X 25/64" LG.
7	4	221416	ROLL PIN, 3/8" X 2" LG.
8	2	226358	PIN WELDMENT
9	1	226363-01	TORSION SPRING, 1/2" X 5-3/4" LG. RH
10	1	226363-02	SPRING, TORSION, 1/2" X 5-3/4" LG. LH
11	2	226365	PIN WELDMENT, SHACKLE
12	2	907026	ROLL PIN, 3/16 X 2-1/4" LG.
13	2	226372	ROUND TUBE, 1/4" (2" X 5/16"W)
14	4	226375	ROLLER, 1"
15	8	226941	NYLON LOCK NUT, 3/8"-24 THIN
16	2	261785-01	PARALLEL ARM WELDMENT (WITH BEARINGS)
16A	8	905112-07	BEARING, SELF-LUBE, 1-3/8" X 1-3/4" LG.
17	1	261800-01	LIFT FRAME WELDMENT
17A	4	915112-01	BEARING, SELF-LUBE, 1-3/8" X 3/4" LG.
17B	4	915112-02	BEARING, SELF-LUBE, 1-3/8" X 1" LG.
18	2	262435	PIN WELDMENT, CYLINDER 1-3/8" DIA
19	2	262437	BUSHING WELDMENT-CYL HOSE CLAMP
20	2	262462	PIN WELDMENT, CYL. 1-3/8" DIA
21	2	265807-01	PIN WELDMENT, PLATFORM 1-3/8" X 13-1/8" LG.
22	1	265811-01	SHACKLE ASSY, LEFT HAND (WITH BEARINGS)
23	1	265811-02	SHACKLE ASSY, RIGHT HAND (WITH BEARINGS)
24	2	265849-01	SADDLE, LOW PROFILE HINGE
25	1	265866-01	MAIN FRAME WELDMENT
26	14	205780	PLASTIC TIE, 7" LG
27	2	266033-01	PIN WELDMENT, UNDERRIDE
28	4	901023	FLANGE LOCK NUT
29	4	901024-3	BOLT, HEX HEAD, 1/2"-13 X 2-1/4" LG.
30	2	902001-2	FLAT WASHER, 3/8"
31	2	902013-21	FLAT WASHER, 1-3/8"
32	2	905128-07	ROLL PIN 1/8" X 2-1/4" LG
33	2	040103-5	LOOM, SPLIT 1/2" X 5" LG

# PLATFORM & FLIPOVER ASSY (NO CART STOP) P/N 265204-01


**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



ITEM	QTY.	PART NO.	DESCRIPTION
1	2	263456-04	HINGE ROD 1/2" DIA X 80-13/16" LG
2	1	263665-01	FLIPOVER WELDMENT, ALUMINUM, 30"
2A	1	265819-01	HANDLE WELDMENT
3	1	265203-01	PLATFORM WELDMENT, ALUMINUM, 30"
4	16	280109	HINGE ASSEMBLY
5	2	280110	HINGE ASSEMBLY
6	4	905015-1	ROLL PIN, 3/16" X 3/4"

# PLATFORM & FLIPOVER ASSY (SINGLE CART STOP) P/N 265462-01




ITEM	QTY.	PART NO.	DESCRIPTION
1	2	263456-04	HINGE ROD 1/2" DIA X 80-13/16" LG
2	1	265203-01	PLATFORM WELDMENT, ALUMINUM, 30"
3	16	280109	HINGE ASSEMBLY
4	2	280110	HINGE ASSEMBLY
5	4	905015-1	ROLL PIN, 3/16" X 3/4"

**MAXON**<sup>®</sup> 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# FLIPOVER (SINGLE CART STOP)

P/N 265457-01




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	263670-01	FLIPOVER WELDMENT, ALUMINUM
1A	1	265819-01	HANDLE WELDMENT
2	1	030406	ROLL PIN, 1/8" X 1"
3	2	030805	COTTER PIN 1/8" X 1"
4	6	253542	BEARING, SELF LUBE 1/2" X 1/2"
5	1	262481-02	ARM, OPENING AND CLOSING, RH
6	1	262508-01	RAMP WELDMENT, SINGLE CART STOP
7	1	262513-01	PIN, 1/2" DIA X 80-39/64" LG
8	1	262514	GAS SPRING
9	2	262515	METAL EYELET END FITING
10	1	262536	SPRING, TORSION, 1/8"
11	1	900047	SCREW, SHOULDER, 1/2" X 3/4" LG
12	2	902022	FLAT WASHER, 1/2"
13	2	905122-02	BEARING, SELF LUBE 1/2" X 5/16"
14	2	905135	PIN, CLEVIS 5/16" X 7/8"

**MAXON**®

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713




# PLATFORM & FLIPOVER ASSY (DUAL CART STOP) P/N 265463-01



ITEM	QTY.	PART NO.	DESCRIPTION
1	2	263456-04	HINGE ROD, 1/2" DIA X 80-13/16" LG
2	1	265203-01	PLATFORM WELDMENT, ALUMINUM, 30"
3	16	280109	HINGE ASSEMBLY
4	2	280110	HINGE ASSEMBLY
5	4	905015-1	ROLL PIN, 3/16" X 3/4"

# FLIPOVER (DUAL CART STOP) P/N 265459-01



ITEM	QTY.	PART NO.	DESCRIPTION
1	1	263670-02	FLIPOVER ASSEMBLY, ALUMINUM
1A	1	265819-01	HANDLE WELDMENT
2	1	030406	ROLL PIN, 1/8" X 1"
3	4	030805	COTTER PIN 1/8" X 1"
4	6	253542	BEARING, SELF LUBE 1/2" X 1/2"
5	1	262481-01	ARM, OPENING AND CLOSING LH
6	1	262481-02	ARM, OPENING AND CLOSING RH
7	1	262509-03	RAMP WELDMENT, DUAL CART STOP, LH
8	1	262509-04	RAMP WELDMENT, DUAL CART STOP, RH
9	1	262513-01	PIN, 1/2" DIA X 80 39/64" LG
10	2	262514	GAS SPRING
11	4	262515	METAL EYELET END FITTING
12	2	900047	SCREW, SHOULDER, 1/2" X 3/4" LG
13	2	902022	FLAT WASHER, 1/2"
14	4	905122-02	BEARING, SELF LUBE 1/2" X 5/16"
15	4	905135	PIN, CLEVIS 5/16" X 7/8"

**MAXON**®


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

THIS PAGE INTENTIONALLY LEFT BLANK

**MAXON**


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# HYDRAULIC COMPONENTS - GRAVITY DOWN




ITEM	QTY.	PART NO.	DESCRIPTION
1	2	266038-01	CYLINDER, 80-3
	2	266039-01	CYLINDER, 80-4
2	1	265846-01	HOSE ASSY 3/8"HP SAE#8F,#6M 21" LG.
3	1	22437-17	PLASTIC HOSE, 14" X 30" LG
4	1	265888-01	HOSE ASSY, 3/8"HP, SAE#8 F-F 57" LG.
5	1	224370-13	PLASTIC HOSE, 14" X 75" LG.
6	1	224370-12	PLASTIC HOSE, 14" X 55" LG.
7	1	265888-02	HOSE ASSY, 3/8"HP, SAE#6 F-F, 77" LG.
8	1	215406	ELBOW, BRASS, 1/4" X 3/8"
9	1	905150	TEE, UNION 3/8" F.S. MALE,6-JLO
10	2	906704-01	ELBOW, STRAIGHT THREAD #8 F/S O-R M-M
11	2	906705-01	CONNECTOR, LONG, NPSC, SAE #6
12	1	906711-01	TEE, UNION AIRBRAKE, 1/4"
13	2	906707-01	ELBOW, STRAIGHT THREAD F/S O-R #6 M-M
14	1	906708-01	ELBOW, STRAIGHT THREAD F/S O-R #6 M-F SW
15	1	906709-01	VALVE, FLOW REGULATOR #6 SAE, 4GPM
16	8	906712-02	O-RING , #6 (3/8" FACE SEAL TUBE-END)
17	2	228012	ADAPTER, STRAIGHT THD. 9/16" TO 1/4" PIPE

# PUMP BOX ASSEMBLY - GRAVITY DOWN



ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266016-01	PUMP BOX WELDMENT
2	1	229383	PUMP BOX COVER
2A	2	215139	CATCH & FASTENER
3	1	266032-01	CABLE ASSEMBLY, 16GA/3-WIRE
4	1	280566-01	GREEN WIRE ASSEMBLY, 16GA
5	1	266014-01	PUMP ASSEMBLY, GRAVITY DOWN
5A	1	280374	MOTOR, 12 VOLTS DC
5B	1	280372	SOLENOID VALVE, 12 VOLTS DC
5C	1	906721-01	RESERVOIR
5D	1	280394	MOTOR STARTER SOLENOID, 12 VOLTS DC
5E	1	280416	WIRE ASSEMBLY (16GA)
5F	1	280404	CABLE ASSEMBLY (2GA)
5G	1	229193	FILLER, BREATHER
5H	1	266030-01	DRAIN PLUG
6	1	REF	DECAL (SEE DECAL SECTION)
7	1	205780	PLASTIC TIE

# HYDRAULIC COMPONENTS - POWER DOWN




ITEM	QTY.	PART NO.	DESCRIPTION
1	2	266038-01	CYLINDER, 80-3
	2	266039-01	CYLINDER, 80-4
2	1	265846-01	HOSE ASSY, 3/8"HP SAE#8F,#6M, 21" LG
3	1	265847-01	HOSE ASSY, 3/8"HP SAE#6 F-F, 28" LG
4	1	265888-01	HOSE ASSY, 3/8"HP SAE#8 F-F, 57" LG
5	1	265888-02	HOSE ASSY, 3/8"HP SAE#8 F-F, 83" LG
6	1	265889-01	HOSE ASSY, 3/8"HP SAE#6 F-F, 55" LG
7	1	265889-02	HOSE ASSY, 3/8"HP SAE#6 F-F, 77" LG
8	1	906709-01	VALVE,FLOW REGULATOR #6 SAE, 4GPM
9	1	905150	TEE, UNION, 3/8" F/S MALE,6-JLO
10	2	906704-01	ELBOW, STRAIGHT THR. #8F/S O-RING M-M
11	2	906705-01	CONNECTOR, LONG STR, THD SAE #6
12	1	906706-01	TEE, UNION SAE#8 F/S M-M
13	2	906707-01	ELBOW, STRAIGHT THD. #6F/S O-RING M-M
14	1	906708-01	ELBOW, STRAIGHT THD F/S O-RING #6M-F SW
15	6	906712-02	O-RING #6 (3/8" FACE SEAL TUBE-END)
16	5	906712-03	O-RING #8 (1/2" FACE SEAL TUBE-END)

**MAXON**®


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# PUMP BOX ASSEMBLY - POWER DOWN




ITEM	QTY.	PART NO.	DESCRIPTION
1	1	266016-01	PUMP BOX WELDMENT
2	1	229383	PUMP BOX COVER
2A	2	215139	CATCH & FASTENER
3	1	266032-01	CABLE ASSEMBLY, 16 GA/3-WIRE
4	1	205780	PLASTIC TIE
5	1	266030-01	PUMP ASSEMBLY, POWER DOWN
5A	1	280381	MOTOR, 12 VOLTS DC
5B	2	280394	MOTOR STARTER SOLENOID, 12 VOLTS DC
5C	2	906719-01	VALVE
5D	2	906720-01	10 VDC COIL
5E	1	906721-01	RESERVOIR
5F	2	280402	CABLE ASSEMBLY (2 GA)
5G	1	280543	CABLE ASSEMBLY (2 GA)
5H	1	229193	FILLER-BREATHER
5I	1	REF	DRAIN PLUG, 3/8"-18 NPTF
6	1	REF	DECAL (SEE DECAL SECTION)

# CONTROL SWITCH AND POWER CABLE



**NOTE:** Use Switch to **RAISE** and **LOWER** Liftgate to make sure Switch operates as shown on the decal.



**⚠ WARNING**  
Do not attach cable to battery until liftgate repairs are completed.

**MAXON**<sup>®</sup>  
11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713






# DECALS - CONTINUED

**MAXON**<sup>®</sup>


11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713



**UP/DOWN DECAL**  
P/N 264507

**WARNING DECAL**  
P/N 264081  
(REFERENCE)

**CAUTION DECAL**  
P/N 263998  
(REFERENCE)



THE MAXIMUM CAPACITY  
OF THIS LIFT IS

**POUNDS**

WHEN THE LOAD IS  
CENTERED ON PLATFORM

**CAPACITY DECAL (SEE TABLE 1)**  
P/N 264081

LIFT CAPACITY DECALS	
CAPACITY	PART NO.
2500 LBS.	220382
3000 LBS.	220388
4000 LBS.	220389
5000 LBS.	220390

**TABLE 1**

## OPERATING INSTRUCTIONS


GPT & 80 SERIES LIFTGATES

- 1** UNHOOK SAFETY CHAIN. (SEE CAUTION DECAL.)
- 2** PUSH CONTROL SWITCH

(MUST TOUCH THE GROUND)
- 3** UNFOLD PLATFORM.
- 4** UNFOLD FLIPOVER.
- 5** USE SWITCH TO RAISE / LOWER.
- 6** TO TUCK UNIT AWAY REVERSE STEPS 1, 2, 3, & 4.

DECAL, P/N 251838

**INSTRUCTION DECAL**  
P/N 251838




## HYDRAULIC FLUID LEVEL

**FILL  
LEVEL**




1. Platform must be open and on the ground to check hydraulic fluid level (see illustration). Remove Filler Cap and look in filler hole. Reservoir is full if fluid level is even with top of **FILL LEVEL** bar.



2. If fluid level is lower than top of **FILL LEVEL** bar, add hydraulic fluid (see **SPECS**). Fill until fluid level is even with top of **FILL LEVEL** bar. Re-install Filler Cap.

### HYDRAULIC FLUID SPECS.



P/N 265330-03


FLUID LEVEL DECAL  
P/N 265330-03

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# SCHEMATICS


# HYDRAULIC SCHEMATIC - GRAVITY DOWN




# ELECTRICAL SCHEMATIC - GRAVITY DOWN

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713




# HYDRAULIC SCHEMATIC - POWER DOWN



# ELECTRICAL SCHEMATIC - POWER DOWN

**MAXON**<sup>®</sup>  
 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713





# TROUBLESHOOTING

# PLATFORM WILL NOT RAISE

1. Connect voltmeter between Motor Solenoid Terminal “A” and Bracket (**FIG. 1**) to verify that battery power is getting to “A”. Recharge the battery if voltmeter indicates less than 12.6 Volts DC.


## CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

2. Fill Reservoir to within 1/2” below the top with the hydraulic fluid recommended in the Periodic Maintenance Checklist.
3. Touch a jumper wire to terminals “A” & “C” (**FIG. 1**). If motor runs check Switch, switch connections, and White wire. Check and correct wiring connections or replace the Switch.
4. Touch heavy jumper cables to terminals “A” & “B” (**FIG. 1**).
  - a. If motor runs, replace the motor solenoid.
  - b. If motor does not run, repair or replace the pump motor.

**NOTE:** In most cases, you can avoid having to manually bleed Hydraulic System by correctly positioning Liftgate Platform before disconnecting any Lifting Cylinder high pressure Hydraulic Lines. The following procedure can save time and prevent accidental fluid spills and hazards.

5. Check for structural damage and replace worn parts.
6. Check filter in the pump Reservoir. Replace filter if necessary.
7. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.



**FIG. 1**

# PLATFORM RAISES BUT LEAKS DOWN

1. Check if Lowering Solenoid Valve is constantly energized. Connect voltmeter negative (-) lead to Motor Solenoid bracket and positive (+) lead to Motor Solenoid terminal "C" (FIG. 2). If voltmeter reads battery voltage (+12.6 Volts DC minimum) without pushing the toggle switch, the control circuit is operating incorrectly. Check if toggle switch, wiring or coil are faulty.




FIG. 2

## CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

**NOTE:** In most cases, you can avoid having to manually bleed Hydraulic System by correctly positioning Liftgate Platform before disconnecting any Lifting Cylinder high pressure Hydraulic Lines. The following procedure can save time and prevent accidental fluid spills and hazards.

2. Check the Valve Stem by removing the Coil Assembly (FIG. 3, Item 1). With platform supported, unscrew the Valve Stem (FIG. 3, Item 2) from the Pump. Push on the plunger located inside the Valve Stem with a small screwdriver. If the Plunger does not move freely (approximately 1/8") replace the Valve Stem.




FIG. 3

3. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (FIG. 4). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.




FIG. 4

# PLATFORM RAISES PARTIALLY AND STOPS

## CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

1. Lower the opened Platform to the ground. Fill the Pump Reservoir on Gravity-Down Liftgates to within 1/2" below the top with hydraulic fluid recommended in Periodic Maintenance Checklist.
2. Use voltmeter to verify that the Battery shows 12.6 volts or more.
3. Check for Structural damage, or poor lubrication. Replace worn parts.

**NOTE:** In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

4. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 5**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.
5. Check Filter in the Pump Reservoir. Replace filter if necessary.
6. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.

**MAXON**<sup>®</sup>

11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# LIFTGATE WILL NOT LIFT RATED CAPACITY

1. Use voltmeter to verify that the Battery shows 12.6 volts or more under load from pump motor.
2. Check for Structural damage or lack of lubrication. Replace worn parts.

## CAUTION

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

**NOTE:** In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

3. With Platform on the ground, remove the pressure hose and fitting from the Pump and replace it with a 0-3000 PSI Pressure Gauge. Hold the switch in the "UP" position. Adjust the Relief Valve on the side of the Pump until the gauge shows 2800 to 3000 PSI (**FIG. 6**). Remove gauge and re-install pressure hose.
4. Check for dirty pump motor relief valve. Clean if necessary. Replace any worn out relief valve parts.
5. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 5**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.
6. If Pump cannot produce 2800-3000 PSI with a minimum of 12.6 Volts available, the Pump is worn and needs to be replaced.




FIG. 5





FIG. 6

RELIEF VALVE  
ADJUST SCREW

# PLATFORM RAISES SLOWLY

1. Connect voltmeter between Motor Solenoid Terminal "A" and Bracket (**FIG. 7**) to verify that battery power is getting to "A". Recharge the battery if voltmeter indicates less than 12.6 Volts DC.





**CAUTION**

Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

2. Check the Hydraulic Cylinder. With the Platform on the ground, remove the Breather Plug or Line from the Down Port of the Cylinder (**FIG. 9**). Raise the Platform even with the bed. Allow pump motor to run two seconds more while you watch for hydraulic fluid at the Down Port. A few drops of hydraulic fluid escaping the Down Port is normal; however, if it streams from the Down Port, Piston Seals are worn. Replace Seals.

**NOTE:** In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.


3. Check and clean Flow Control Valve (**FIG. 8**) in high pressure hydraulic line attached to Cylinder. When installing Flow Control Valve make sure arrow on valve is oriented as shown in **FIG. 8**.
4. Lower the opened Platform to the ground. Fill the Pump Reservoir on Gravity-Down Liftgates to within 1/2" below the top with hydraulic fluid recommended in Periodic Maintenance Checklist.
5. Verify the Pump Motor is grounded to the vehicle frame.
6. Check for leaking hoses and fittings. Tighten or replace as required.
7. Check for structural damage or poor lubrication. Replace worn parts.
8. Check the Filter in the Pump Reservoir. Replace if necessary.
9. With Platform on the ground, remove the pressure hose and fitting from the Pump and replace it with a 0-3000 PSI Pressure Gauge. Hold the Control switch in the "RAISE" position. Adjust the Relief Valve on the side of the Pump until the gauge shows 2800 to 3000 PSI (**FIG. 9**). Remove gauge and re-install pressure hose.



**MAXON**<sup>®</sup>  
 11921 Slauson Ave. Santa Fe Springs, CA. 90670 (800) 227-4116 FAX (888) 771-7713

# PLATFORM WILL NOT LOWER, LOWERS TOO SLOWLY, OR LOWERS TOO QUICKLY

1. Connect voltmeter between Motor Solenoid Terminal "A" and Bracket (**FIG. 10**) to verify that battery power is getting to "A". Recharge the battery if voltmeter indicates less than 12.6 Volts DC.
2. Check for structural damage or poor lubrication. Replace worn parts.
3. Check if Lowering Solenoid Valve is getting power. Connect voltmeter between Motor Solenoid Bracket and Motor Solenoid terminal "C" (**FIG. 10**). Push Control Switch to "LOWER" position to energize Lowering Solenoid. If voltmeter reads battery voltage (+12.6 Volts DC minimum), control circuit is operating correctly (replace Lowering Solenoid). If voltmeter reads 0 Volts, check if toggle switch and wiring are faulty.




**FIG. 10**

## CAUTION


Keep dirt, water and other contaminants from entering the hydraulic system. Before opening the hydraulic fluid reservoir filler cap, drain plug and hydraulic lines, clean up contaminants that can get in the openings. Also, protect the openings from accidental contamination during maintenance.

**NOTE:** In most cases, you can avoid having to bleed the hydraulic system by correctly positioning Liftgate Platform before opening hydraulic lines. Refer to following procedure. Save time on the job and prevent accidental fluid spills and hazards.

4. Check the Valve Stem by removing the Coil Assembly (**FIG. 11, Item 1**). With platform supported, unscrew the Valve Stem (**FIG. 11, Item 2**) from the Pump. Push on the plunger located inside the Valve Stem with a small screwdriver. If the Plunger does not move freely (approximately 1/8") replace the Valve Stem.
5. Check if filtering screen on solenoid valve is plugged. Clean carefully if required.
6. Check and clean Flow Control Valve in high pressure hydraulic line attached to Cylinder.
7. Check if Flow Control Valve (**FIG. 12**) is pointing to the direction of restricted fluid flow (back toward pump). If required, remove Flow Control Valve and install it correctly (**FIG. 12**).



**FIG. 11**



**FIG. 12**