

INSTRUCTION, SAFETY BELT INSTALLATION KIT (WL7A) P/N 267492-01





CAP SCREW, 5/16"-18 X 3/4" LG, GRADE 8 P/N 900009-3 QTY. 3



CAP SCREW, 5/16"-18 X 1-1/4" LG, GRADE 8 P/N 900009-5 QTY. 1



LOCK NUT, 5/16"-18 P/N 901001 QTY. 4




HEX NUT, 5/16"-18 P/N 901011-3 QTY. 1




FLAT WASHER, 5/16" P/N 902000-7 QTY. 4

MAXON[®] LIFT CORPORATION Sht. 2 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05

See the WL7 Operation Manual (MP-05-11) for operating instructions. Then apply power to the Lift by turning ON the switch on the Pump Cover (MP-05-11). Next UNFOLD the Lift and lower the Platform to ground level (FIG. 2-1). Remove power from the Lift by turning OFF the switch on the Pump Cover (MP-05-11).




2. Remove rubber grommet from Right Hand RH side Handrail (FIGS. 2-2A and 2-2B).




MAXON[®] LIFT CORPORATION Sht. 3 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05

3. Fish the wiring harness from the RH side Handrail (**FIG. 3-1**) and then feed it through the Rubber Grommet. Reinstall the Rubber Grommet.




FISHING WIRING HARNESS FROM RH SIDE HANDRAIL FIG. 3-1

4. Unbuckle the Safety Belt (Kit item) **(FIG. 3-2)**.



UNBUCKLING SAFETY BELT FIG. 3-2


5. Bolt the part of the Safety Belt, with the electrical wiring, to the RH side Handrail **(FIG. 3-3)**.



BOLTING SAFETY BELT TO RH SIDE HANDRAIL FIG. 3-3


MAXON® LIFT CORPORATION Sht. 4 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05

6. Connect the Safety Belt wiring harness to the Handrail wiring harness. Feed the extra wiring back in the Handrail until the loom reaches the grommet. (FIG. 4-1).




CONNECTING SAFETY BELT WIRING HARNESS TO HANDRAIL WIRING HARNESS FIG. 4-1

NOTE: The 1-1/4" long cap screw goes in the bottom hole on the Handrail bracket.




MAXON® LIFT CORPORATION Sht. 5 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05




MAXON® LIFT CORPORATION Sht. 6 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05

9. Adjust the Safety Belt length until it will buckle (**FIG. 6-1**). Then add another 3" to 4" of slack.



ADJUSTING LENGTH OF SAFETY BELT FIG. 6-1


10. Use the Hand Control to raise **UP** the Platform off the ground as shown in **FIG. 6-2**.



PLATFORM RAISED ABOVE GROUND LEVEL FIG. 6-2

MAXON® LIFT CORPORATION Sht. 7 of 7 DSG# MP-05-04 Rev. - Date: 11/30/05

11. Unbuckle the Safety Belt (**FIG. 7-1**). Use the Hand Control to raise **UP** the Platform. Platform should not raise and Controller should read **SEAT BLT (FIG. 7-2)**.



UNBUCKLING SAFETY BELT FIG. 7-1




CONTROLLER READING FIG. 7-2

12. Buckle the Safety Belt (**FIG. 7-3**). Use the Hand Control to raise the Platform to floor level. Platform should raise to floor level (**FIG. 7-4**).



BUCKLING SAFETY BELT FIG. 7-3



PLATFORM RAISED TO FLOOR LEVEL FIG. 7-4

13. Stow the Lift (see MP-05-11).